

CONEX-AGP

**Agilis-P Controller
with Encoder Feedback**



Warranty

Newport Corporation warrants that this product will be free from defects in material and workmanship and will comply with Newport's published specifications at the time of sale for a period of one year from date of shipment. If found to be defective during the warranty period, the product will either be repaired or replaced at Newport's option.

To exercise this warranty, write or call your local Newport office or representative, or contact Newport headquarters in Irvine, California. You will be given prompt assistance and return instructions. Send the product, freight prepaid, to the indicated service facility. Repairs will be made and the instrument returned freight prepaid. Repaired products are warranted for the remainder of the original warranty period or 90 days, whichever occurs last.

Limitation of Warranty

The above warranties do not apply to products which have been repaired or modified without Newport's written approval, or products subjected to unusual physical, thermal or electrical stress, improper installation, misuse, abuse, accident or negligence in use, storage, transportation or handling.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE. NEWPORT CORPORATION SHALL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE PURCHASE OR USE OF ITS PRODUCTS.

©2026 by Newport Corporation, Irvine, CA. All rights reserved.

Original instructions.

No part of this document may be reproduced or copied without the prior written approval of Newport Corporation. This document is provided for information only, and product specifications are subject to change without notice. Any change will be reflected in future publishings.

Table of Contents

Warranty	ii
1.0 System Overview.....	1
1.1 General Description.....	1
1.1.1 Encoder Theory of Operation	2
1.1.2 Closed Loop Technology – Deadband Feature	3
1.2 CONEX-AGP	4
1.2.1 Delivered Items	4
1.2.2 Specifications.....	4
1.2.3 Dimensions	5
1.3 System Environmental Specifications	6
1.4 Connector Identification	6
1.5 USB Communication Settings	6
2.0 Programming.....	7
2.1 State Diagram.....	7
2.2 Command Syntax	9
2.3 Command Execution Time	9
2.4 Command Set.....	9
DB — Set/Get corrector deadband.....	11
HT — Set/Get HOME search type.....	12
ID — Set/Get stage identifier.....	13
IF — Set/Get interpolation factor.....	14
KI — Set/Get integral gain	15
KP — Set/Get proportional gain	16
LF — Set/Get low pass filter frequency	17
MM — Enter/Leave DISABLE state.....	18
OR — Execute HOME search	20
PA — Move absolute	21
PR — Move relative.....	22
PW — Enter/Leave CONFIGURATION state	23
RS — Reset controller.....	24
RS## — Reset controller’s address.....	25
SA — Set/Get controller’s RS-485 address	26
SL — Set/Get negative software limit.....	27
SR — Set/Get positive software limit.....	28
ST — Stop motion.....	29
SU — Set/Get encoder increment value	30

TB — Get command error string.....

31

TE — Get last command error

32

TH — Get target position

33

TP — Get current position.....

34

TS — Get positioner error and controller state

35

VE — Get controller revision information

37

ZT — Get all configuration parameters.....

38

3.0 Connector interfaces.....

39

3.1 USB (Male mini-USB).....

39

Service Form

41



Agilis-P Controller with Encoder Feedback CONEX-AGP

1.0 System Overview


1.1 General Description

The CONEX-AGP is a single axis motion controller/driver for piezo actuator with encoder feedback. It provides a very compact and low-cost solution for driving a variety of Newport Agilis-type piezo stages from a PC.

Communication with the CONEX-AGP is achieved via an USB port (requires Windows™ operating system). A Windows™ based software enables basic motion. Advanced application programming is simplified by an ASCII command interface and a set of two letter mnemonic commands.

1.1.1 Encoder Theory of Operation


The encoder on the Agilis stage is generated from a proprietary marking technology that creates a pattern of fine lines directly on the stage. From these patterns, sinusoidal signals are generated which are then interpolated by the encoder electronics down to the specified resolution. The accuracy of the stage is very dependent on the quality of the pattern, which also leads to high positioning repeatability.



1.1.2 Closed Loop Technology – Deadband Feature

The Conex closed loop algorithm for Agilis stages is a simplified version of the typical DC servo loop algorithm. Although a motion profile is not generated in the algorithm, the Conex controller still closes a loop based on the error. The larger the error, the faster the stage is commanded to move to reduce the error. The stage could start at the full system speed of 1700 pulses if the stage is far from the desired position.

To close in on a position, the motion of the stage stops when the stage is within a specified range about the desired position. This range is called the deadband and is set in firmware. The deadband is the allowable deviation from the desired position and if the stage is inside the deadband within 20 ms, the stage is considered in position and stops.



NOTE

The servo loop can be disabled to eliminate any undesired correction of the position when the stage moves outside the deadband due to external sources.

1.2 CONEX-AGP

1.2.1 Delivered Items


- CONEX-xxx Controller box with stage (cable length: 1 m)
- CONEX-USB USB cable, 1.8 m length
- CONEX-MOTION CD-Rom



1.2.2 Specifications

General Description	Agilis controller with encoder feedback.
Control Capability	Piezo motors, closed loop
Piezo Output Voltage	35 V _{peak}
Control loop	– Digital PI loop – 100 Hz servo rate
Motion	Absolute and relative motion.
Computer interface	– USB (requires Windows™ operating system)
Programming	– 25+ intuitive, 2-letter ASCII commands – Command set includes software limits, user units...
Dedicated inputs	– Analog Cosine/Sine signals from encoder.
Status display	Two color LED
Communication rate	50 Hz Max. (USB)
Internal safety feature	Watchdog timer
Consumption +5V (USB):	<0.5A


1.2.3 Dimensions



1.3 System Environmental Specifications

Operating temperature	5 °C to 40 °C
Operating humidity	20% to 85% relative humidity, non-condensing
Location	Indoor use only

1.4 Connector Identification



USB	mini USB connector
LED	Status LED
STAGE	Stage entry cable
Cable retainer	2 x M3 threaded hole to attach cable retainer

1.5 USB Communication Settings


Communication parameters are preset in the CONEX-AGP controller and do not require any configuration:

Bits per second	921,600
Data bits	8
Parity	None
Stop bits	1
Flow control	Xon/Xoff
Terminator	C _R L _F

2.0 Programming

2.1 State Diagram

For a safe and consistent operation, the CONEX-AGP uses 6 different operational states: Not referenced, Configuration, Homing, Ready, Disable and Moving. In each state, only specific commands are accepted by the CONEX-AGP. Therefore, it is important to understand the state diagram below and which commands and actions cause transitions between the different states. See section 2.4 for additional command/state information:



LED display:

NOT REFERENCED:	If everything is OK then SOLID ORANGE.
NOT REFERENCED:	If no parameters then SOLID RED.
CONFIGURATION:	SLOW BLINKING RED.
READY:	SOLID GREEN.
DISABLE:	SLOW BLINKING GREEN.
HOMING:	FAST BLINKING GREEN.
MOVING:	FAST BLINKING GREEN.

When powering the CONEX-AGP, the controller starts initialization. When the initialization is successful, the controller goes to the NOT REFERENCED state. From the NOT REFERENCED state, the controller can go to the CONFIGURATION state using the PW1 command. In the CONFIGURATION state, the CONEX-AGP allows changes to all configuration parameters, like corrector coefficients or travel limits. The PW0 command saves all changes to the controller's memory and returns the controller back to the NOT REFERENCED state.

To execute any move commands (PA, PR), the controller must be in the READY or MOVING states. To get from the NOT REFERENCED state to the READY state, the positioner must be homed first with the OR command. During homing (OR command execution), the controller is in HOMING state. When homing is successful, the controller automatically goes to the READY state. The process for homing and the signals utilized during homing can be defined with the HT command.

In the READY state, the control loop is closed. During a move execution (PA/PR), the controller is in the MOVING state and goes automatically back to the READY state when the move is completed. A time out error during a move changes the controller to the DISABLE state.

In the DISABLE state, the control loop is open. But the encoder is still read and the current position gets updated. The DISABLE state can be used to make sure that the control loop will not generate any corrective motion command (due to noise or little drift) while at a given position. To go from the READY state to the DISABLE state and vice versa, use the MM command.

To get from the READY or DISABLE states back to the NOT REFERENCED state, to make some further parameter changes in CONFIGURATION state, for example, you need to reboot the controller with the RS command.

2.2 Command Syntax

The CONEX-AGP is a command driven controller. The general format of a command is a two letter ASCII character preceded and followed by parameters specific to the command:

Command format:

nn	AA	xx
-----------	-----------	-----------

nn — Optional or required controller address.

AA — Command name.

xx — Optional or required value or “?” to query current value.

Both, upper and lower case characters are accepted. Depending on the command, it can have an optional or required prefix (**nn**) for the controller address and/or a suffix (**xx**) value or a “?”.

Blank spaces

Blanks are allowed and ignored in any position, including inside a numerical value. The following two commands are equivalent, but the first example might be confusing and uses more memory:

2P A1.43 6

2PA1.436

Decimal separator

A dot (“.”) is used as decimal separator for all numerical values.

Command terminator

Commands are executed as the command terminator C_RL_F (carriage-return line-feed, ASCII 13 and ASCII 10) is received. The controller will analyze the received string. If the command is valid and its parameters are in the specified range, it will be executed. Otherwise it will memorize an error.

After the execution of the command, all remaining characters in the input string, if any, will be ignored. In particular, it is not possible to concatenate several commands on a single string from the PC to the CONEX-AGP

Each command will handle the memorization of related errors that can be accessed with the TE command properly. Please refer to the command set in section 2.4 for details.

2.3 Command Execution Time

The CONEX-AGP controller interprets commands continuously as received. The typical execution time for a "tell position command" (nTP?) is about 10 ms. Here, command execution time means the time from sending the command until receipt of the answer.

It is important to note that a move command, that may last for several seconds, will not suspend the controller from further command execution. For an efficient process flow with many move commands, it is recommended to query the controller status (TS command) or the current position (TP command) before any further motion command is sent.

2.4 Command Set

This section describes the supported two-letter ASCII commands used to configure and operate the CONEX-AGP. The general command format is:

Command format:

nn	AA	xx
-----------	-----------	-----------

nn — Optional or required controller address.

AA — Command name.

xx — Optional or required value or “?” to query current value.

Most commands can be used to set a value (in that case the command name is followed by the value “xx”) or to query the current value (in that case the command name is followed by a “?”). When querying a value, the controller responds with the command it received followed by the queried value. For example, a 1LF20 sets the low pass filter frequency of the controller #1 to 20 Hz. A 1LF? sends the response 1LF20.

Not every command can be executed in all states of the CONEX-AGP and some commands have different meanings in different states. It is therefore important to understand the state diagram of the controller, see section 2.1.

	Not Ref.	Config.	Disable	Ready	Motion	Description
DB	☐	☐	☐	—	—	Set/Get corrector deadband
HT	☐	☐	—	—	—	Set/Get HOME search type
ID	☐	☐	☐	—	—	Set/Get stage identifier
IF	☐	☐	☐	—	—	Set/Get interpolation factor
KI	☐	☐	☐	—	—	Set/Get integral gain
KP	☐	☐	☐	—	—	Set/Get proportional gain
LF	☐	☐	☐	—	—	Set/Get low pass filter frequency
MM	—	—	●	●	—	Enter/Leave DISABLE state
OR	●	—	—	—	—	Execute HOME search
PA	—	—	—	●	●	Move absolute
PR	—	—	—	●	●	Move relative
PW	●	●	—	—	—	Enter/Leave CONFIGURATION state
RS	●	●	●	●	●	Reset controller
RS##	●	●	●	●	●	Reset controller's address to 1
SA	—	☐	—	—	—	Set/Get controller's RS-485 address
SL	—	☐	☐	☐	—	Set/Get negative software limit
SR	—	☐	☐	☐	—	Set/Get positive software limit
ST	—	—	—	—	●	Stop motion
SU	—	☐	—	—	—	Set/Get encoder increment value
TB	●	●	●	●	●	Get command error string
TE	●	●	●	●	●	Get last command error
TH	●	●	●	●	●	Get target position
TP	●	●	●	●	●	Get current position
TS	●	●	●	●	●	Get positioner error and controller state
VE	●	●	●	●	●	Get controller revision information
ZT	●	●	●	—	—	Get all controller parameters

Motion:

Corresponds to HOMING and MOVING state (for details see state diagram, section 2.1).

○

Changes configuration parameters. Those changes will be stored in the controller's memory with the PW1 command and remain available after switching off the controller.

□

Changes working parameters only. Those changes will get lost when switching off the controller.

●

Accepted command.

—

Write command not accepted (will return an error).

Command:

Command passed without preceding controller number applies to all controllers (e.g. MM0 disables all controllers).

DB — Set/Get corrector deadband

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		□	○	□	—	—
Syntax	xxDBnn or xxDB?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Deadband value.			
Range	xx	—	1 to 31			
	nn	—	≥ 0 and <0.05			
Units	xx	—	None			
	nn	—	Preset units			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	The deadband parameter defines an area, around a set position, in which the controller will not try to make any more corrections. This is useful to prevent the corrector from generating unwanted motion, for example because of noise on the encoder.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	KI	—	Set the integral gain.			
	KP	—	Set the proportional gain.			
Example	1DB0.000075 Set controller #1 deadband to 75 nm (in the case of a translation stage).					

HT — Set/Get HOME search type

Usage	Not Ref.	Config.	Disable	Ready	Motion
	□	○	—	—	—
Syntax	xxHTnn or xxHT?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [int]	—	Home type value.		
Range	xx	—	1 to 31		
	nn	—	1 use current position as HOME.		
			4 use negative end of run as HOME		
			5 end of run offset initialization		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	This command sets the type of HOME search used with the OR command.				
	To improve repeatability of the Home position, the stage does not use the mechanical end of run, but a position a little away from it defined by a precise position of the encoder signal. This position is stored in the controller memory the first time the stage is used in mode 4 (default), without action required from the user.				
	Mode 5 is a maintenance mode and must be used by Newport service personnel only.				
	* The maximum number of times that parameter can be stored to the memory is limited to 100 writes. Unit failure due to excessive use of the command is not covered by warranty.				
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Rel. Commands	OR	—	Execute HOME search.		
Example	1HT1		Set controller #1 HOME sequence to use current position as home.		

ID — Set/Get stage identifier

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		□	○	□	—	—
	Syntax	xxIDnn or xxID?				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [char]	—	Stage model number.			
Range	xx	—	1 to 31			
	nn	—	1 to 31 ASCII characters.			
Units	xx	—	None			
	nn	—	None			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	The ID? command return the product name. In CONFIGURATION mode, this command allows changing the controller identifier.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
		—				
Rel. Commands	ZT	—	Get configuration parameters.			
Example	IID?		Get stage identifier for controller #1.			
	IID CONEX-AGP		Controller returns product namer: CONEX-AGP.			

IF — Set/Get interpolation factor

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		□	○	□	—	—
	Syntax	xxIFnn or xxIF?				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Hysteresis value.			
Range	xx	—	1 to 31			
	nn	—	>0 and ≤2000			
Units	xx	—	None			
	nn	—	None			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	The IF command sets the interpolation factor. The interpolation defines the number by which is divided the encoder resolution to define the interpolated resolution.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	SU	—	Set/Get encoder resolution			
Example	1IF1000		Set controller #1 interpolation factor to 1000.			

KI — Set/Get integral gain

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		□	○	□	—	—
Syntax	xxKI _{nn} or xxKI?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Integral gain value.			
Range	xx	—	1 to 31			
	nn	—	≥ 0 and ≤3000			
Units	xx	—	None.			
	nn	—	Volt * preset unit/second.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	In CONFIGURATION state, this command sets the integral gain of the PI control loop which can then be saved in the controller’s nonvolatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE state. In DISABLE state, this command allows setting a new working parameter for the integral gain. This value is not saved in the controller’s memory and will be lost after reboot.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	KP	—	Set proportional gain.			
Example	1KI800		Set controller #1 integral gain to 800.			

KP — Set/Get proportional gain

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		□	○	□	—	—
Syntax	xxKPnn or xxKP?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Proportional gain value.			
Range	xx	—	1 to 31			
	nn	—	≥ 0 and <3000			
Units	xx	—	None.			
	nn	—	Volt/preset unit			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	In CONFIGURATION state, this command sets the proportional gain of the PI control loop which can than be saved in the controller’s nonvolatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE state.					
	In DISABLE state, this command allows setting a new working parameter for the proportional gain. This value is not saved in the controller’s memory and will be lost after reboot.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	KI	—	Set integral gain.			
Example	1KP10		Set controller #1 proportional gain to 10.			

LF — Set/Get low pass filter frequency

Usage	Not Ref.	Config.	Disable	Ready	Motion
	□	○	□	—	—
Syntax	xxLFnn or xxLF?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [float]	—	Friction compensation value.		
Range	xx	—	1 to 31		
	nn	—	>0 and ≤1000		
Units	xx	—	None.		
	nn	—	Hertz.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	This commands sets the low pass filter frequency used on both sine and cosine inputs coming from the optical encoder.				
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Example	1LF10		Set controller #1 low pass filter to 10 Hz.		

MM — Enter/Leave DISABLE state

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	—	●	●	—
Syntax	xxMMnn or xxMM?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [float]	—	Velocity feed forward value.		
Range	xx	—	0 to 31		
	nn	—	0 changes state from READY to DISABLE. 1 changes state from DISABLE to READY.		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Change to 0.		
		Out of range:	Error B.		
		Floating point:	Error A.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	When the MM command is sent without preceding controller number or the controller number is 0, the MM command gets executed on all controllers.				
	MM0 changes the controller’s state from READY to DISABLE. In DISABLE state the control loop is open. The encoder, though, is still read and the current position gets updated.				
	MM1 changes the controller’s state from DISABLE to READY. The controller’s set point position is set equal to its current position and the control loop gets closed.				
Returns	If the sign “?” takes place of nn, this command returns the current controller state (ef).				
	<u>Controller states (ef):</u>				
	— 0A: NOT REFERENCED from reset.				
	— 0B: NOT REFERENCED from HOMING.				
	— 0C: NOT REFERENCED from CONFIGURATION.				
	— 0D: NOT REFERENCED from DISABLE.				
	— 0E: NOT REFERENCED from READY.				
	— 0F: NOT REFERENCED from MOVING.				
	— 10: NOT REFERENCED no parameters.				
	— 14: CONFIGURATION.				
	— 1E: HOMING.				
	— 28: MOVING.				
	— 32: READY from HOMING.				
	— 33: READY from MOVING.				
	— 34: READY from DISABLE.				
	— 3C: DISABLE from READY.				
	— 3D: DISABLE from MOVING.				

Errors	A	—	Unknown message code or floating point controller address.
	B	—	Controller address not correct.
	C	—	Parameter missing or out of range.
	D	—	Execution not allowed.
	H	—	Execution not allowed in NOT REFERENCED state.
	I	—	Execution not allowed in CONFIGURATION state.
	L	—	Execution not allowed in HOMING state.
Rel. Commands	M	—	Execution not allowed in MOVING state.
	PW	—	Enter/leave CONFIGURATION state.
Example	MM0		<i>All controllers go to DISABLE state</i>
	MM?		
	MM3C		

OR — Execute HOME search

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	—	—	—	—
	Syntax	xxOR				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	This command starts the execution of the HOME search as defined by the HT command.					
	When in NOT REFERENCED state, for instance after system start, any positioner must first get homed with the OR command before further motion commands can get executed.					
	The OR command gets accepted only in NOT REFERENCED state.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	I	—	Execution not allowed in CONFIGURATION state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
	Rel. Commands	HT	—	Set HOME search type.		
Example	1OR		Execute HOME search with controller #1.			

PA — Move absolute

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	—	—	●	●
	Syntax	xxPAnn or xxPA?				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	New target position.			
Range	xx	—	1 to 31			
	nn	—	> SL and < SR			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	Floating point:	Error A.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	The PA command initiates an absolute move. When received, the positioner will move to the new target position specified by nn .					
	The PA command gets only accepted in READY or MOVING state, AND when the new target position is higher or equal to the negative software limit (SL), AND lower or equal to the positive software limit (SR).					
Returns	If the sign “?” takes place of nn , this command returns the target position value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	G	—	Target position out of limits.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
	J	—	Execution not allowed in DISABLE state.			
Rel. Commands	PR	—	Move relative.			
	TH	—	Get target position.			
	TP	—	Get current position.			
	SU	—	Set encoder increment value.			
Example	1PA2.2		Move positioner on controller #1 to absolute position 2.2 units.			

PR — Move relative

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	—	—	●	●
	Syntax	xxPRnn				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Displacement.			
Range	xx	—	1 to 31			
	nn	—	> SL and < SR			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	The PR command initiates a relative move. When received, the positioner will move to a new target position nn units away from the current target position.					
	The PR command gets only accepted in READY or MOVING state, AND when the distance of the positioner to the end of runs is larger than the commanded displacement.					
Returns	If the sign “?” takes place of nn, this command returns the target position value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	G	—	Displacement out of limits.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
	J	—	Execution not allowed in DISABLE state.			
. Commands	PA	—	Move absolute.			
	TH	—	Get target position.			
	TP	—	Get current position.			
	SU	—	Set encoder increment value.			

Example 1PR2.2 | *Move positioner on controller #1 to a new position 2.2 units away from the current target position.*

PW — Enter/Leave CONFIGURATION state

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	—	—	—
Syntax	xxPWnn or xxPW?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [float]	—	Mode.		
Range	xx	—	1 to 31		
	nn	—	1: Go from NOT REFERENCED state to CONFIGURATION state. 0: Go from CONFIGURATION state to NOT REFERENCED state.		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	PW1 changes the controller's state from NOT REFERENCED to CONFIGURATION. In Configuration state all parameter settings are saved in the controller's memory and remain available after switching off the controller. In addition, some settings are only possible in CONFIGURATION state (e.g. set encoder increment value, etc.). PW0 checks all stage parameters, and if they are acceptable, saves them in the flash memory of the controller. After that, it changes the controller's state from CONFIGURATION to NOT REFERENCED. The execution of a PW0 command may take up to 10 seconds. During that time the controller will not respond to any other command.				
Returns	If the sign “?” takes place of nn, this command returns the current state.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Rel. Commands	MM	—	Enter/Leave DISABLE state.		
Example	1PW1		Changes controller #1 to CONFIGURATION state.		

NOTE

The PW command is limited to 100 writes. Unit failure due to excessive use of the PW command is not covered by warranty.

The PW command is used to change the configuration parameters that are stored in memory, and not parameters that are needed to be changed on the fly.

RS — Reset controller

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxRS				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
Description	The RS command issues a hardware reset of the controller, equivalent to a power-up. To go from DISABLE or READY state to CONFIGURATION state, it is also needed to first reset the controller with the RS command, and then to change the controller's state with the PW1 command from NOT REFERENCED to CONFIGURATION.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	D	—	Execution not allowed.		
Example	1RS		Reset controller #1.		

RS## — Reset controller's address

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxRS## or RS##				
Parameters					
Description	xx [int]	—	Axis number.		
Range	xx	—	0 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Change to 0.		
		Out of range:	Error B.		
		Floating point:	Error A.		
Description	The RS## command resets the controller’s address to 1. This address needs to be different for each CONEX devices when connected on a RS-485 communication network.				
Returns					
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Example	RS##		Reset controller’s address to 1.		

SA — Set/Get controller's RS-485 address

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	○	—	—	—
Syntax	xxSAnn or xxSA?				
Parameters					
Description	xx [int]	—	Axis number.		
	nn [int]	—	Controller’s axis number.		
Range	xx	—	1		
	nn	—	2 to 31		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	The SA command sets the controller’s RS-485 address. This address is ONLY used when the controller is configured for RS-485 communication. Newport recommends using the supplied utility software for all controller configurations. The SA command is of practical use only when not using this software.				
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Example	1SA3		Set controller’s RS-485 address to 3.		

SL — Set/Get negative software limit

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	□	□	—
Syntax	xxSLnn or xxSL?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Negative software limit.			
Range	xx	—	1 to 31			
	nn	—	> -10 ¹² and ≤0			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	In CONFIGURATION state, this command sets the negative software limit which can than be saved in the controller’s nonvolatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE or READY state.					
	In DISABLE or READY state, this command allows setting a new working parameter for the negative software limit. It must be lower or equal to the target position. This value is not saved in the controller’s memory and will be lost after reboot.					
	The software limits are useful to limit the travel range of a positioner. There is no possibility to disable software limits. For an almost infinite motion, for instance with a rotation stage, set the lowest possible value, which is: -2147000000 * "encoder increment value" (see SU command). For instance if the encoder increment value is 0,0005, this limit is -1073500.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	SR	—	Set positive software limit.			
Example	1SL-100		Set controller #1 negative software limit to -100 units.			

SR — Set/Get positive software limit

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	□	□	—
Syntax	xxSRnn or xxSR?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Positive software limit.			
Range	xx	—	1 to 31			
	nn	—	≥ 0 and <10 ¹²			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	In CONFIGURATION state, this command sets the positive software limit which can than be saved in the controller’s nonvolatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE or READY state.					
	In DISABLE or READY state, this command allows setting a new working parameter for the positive software limit. It must be larger or equal to the target position. This value is not saved in the controller’s memory and will be lost after reboot.					
	The software limits are useful to limit the travel range of a positioner. There is no possibility to disable software limits. For an almost infinite motion, for instance with a rotation stage, set the largest possible value, which is: 2147000000 * "encoder increment value" (see SU command). For instance if the encoder increment value is 0,0005, this limit is 1073500.					
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	SL	—	Set negative software limit.			
Example	1SR100		Set controller #1 positive software positive to 100 units.			

ST — Stop motion

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	—	—	—	●
	Syntax	[xx]ST				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	0 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Change to 0.			
		Out of range:	Error B.			
		Floating point:	Error A.			
Description	The xxST command with preceding controller address stops a move in progress on controller xx. The ST command without preceding controller address stops the moves on ALL controllers.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
Example		ST		Stop moves on all controllers.		

SU — Set/Get encoder increment value

Usage	Not Ref.	Config.	Disable	Ready	Motion
	–	○	–	–	–
Syntax	xxSUnn or xxSU?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [float]	—	Equivalent units to one encoder count.		
Range	xx	—	1 to 31		
	nn	—	>10 ⁻⁶ and <10 ¹²		
Units	xx	—	None.		
	nn	—	Units.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	The SU command sets the value for one encoder count. It defines also the system of units for all other parameters like travel limits, etc. Therefore, it is the first parameter to be defined for any positioner.				
	<u>Example:</u> For a positioner with an encoder resolution of 1 μm, the command xxSU0.001 sets 1 encoder count = 1 μm = 0.001 unit or 1 unit = 1 mm.				
Returns	If the sign “?” takes place of nn, this command returns the current programmed value.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Example	1SU7.5e-6		Set controller #1 encoder increment to 7.5 * 10 ⁻⁶ units.		

TB — Get command error string

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
	Syntax	xxTBnn				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
	nn [char]	—	Error code (refer to TE command).			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Returns explanation of current error.			
		Out of range:	Error C.			
Description	The TB command returns a string that explains the meaning of the error code nn (see TE command for complete list).					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
Rel. Commands	TE	—	Get error code.			
Example	1TB@		Get explanation to error code @.			
1TB@ No error Controller returns: @ = means no error.						

TE — Get last command error

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
Syntax	xxTE					
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
Description	The TE command returns the currently memorized error. When a command is not executable, it memorizes an error. This error can be read with the TE command. After the execution of a TE command, the error buffer gets erased and another TE command will return @, means no error. When a new command error is generated before the previous command error is read, the new command error will overwrite the current memorized error. For a safe program flow it is recommended to always query the command error after each command execution.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	D	—	Execution not allowed.			
Rel. Commands	TB	—	Get error string.			
Example	1TE		<i>Get last error memorized on controller #1.</i>			
			<i>Controller returns: 1TE@, means no error.</i>			
	List of errors and corresponding strings (see TB command):					
	@	—	No error.			
	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Command not allowed.			
	E	—	Home sequence already started.			
	G	—	Displacement out of limits.			
	H	—	Command not allowed in NOT REFERENCED state.			
	I	—	Command not allowed in CONFIGURATION state.			
	J	—	Command not allowed in DISABLE state.			
	K	—	Command not allowed in READY state.			
	L	—	Command not allowed in HOMING state.			
	M	—	Command not allowed in MOVING state.			
	N	—	Current position out of software limit.			
	S	—	Communication Time Out.			
	U	—	Error during EEPROM access.			
	V	—	Error during command execution.			

TH — Get target position

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
	Syntax	xxTH				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
Description	The TH command returns the value of the target position. This is the position where the positioner should be.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
Rel. Commands	TP	—	Get current position.			
Example	1TH		Get target position of controller #1.			
	1TH0		Controller returns: target position = 0 units.			

TP — Get current position

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
	Syntax	xxTP				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
Description	The TP command returns the value of the current position. This is the position where the positioner actually is according to his encoder value. In MOVING state, this value always changes. In READY state, this value should be equal or very close to the target position.					
	Together with the TS command, the TP command helps evaluating whether a motion is completed.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	D	—	Execution not allowed			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
Rel. Commands	TH	—	Get target position.			
Example	1TP		Get current position of controller #1.			
	1TP0		Controller returns: actual position = 0 units.			

TS — Get positioner error and controller state

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxTS				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
Description	The TS command returns the positioner error and the current controller state.				
Returns	The TS command returns six characters (1TSabcdef). The first 4 characters (abcd) represent the positioner error in Hexadecimal. The last two characters (ef) represent the controller state.				

Error code (abcd): Convert each hexadecimal to a binary:

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
1111	1110	1101	1100	1011	1010	1001	1000	0111	0110	0101	0100	0011	0010	0001	0000

FEach bit represents one possible error:

A				B				C				D			
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
• Not used	• Not used	• Not used	• Not used	• Not used	• Not used	• Not used	• Not used	• No parameters in memory	• Not used	• Motion Time out	• Not used	• Not used	• Not used	• Not used	• Not used

Examples:

- Error map 0000 = No errors
- Error map 0020 = Motion time out

Controller states (ef):

- **0A:** NOT REFERENCED from reset.
- **0B:** NOT REFERENCED from HOMING.
- **0C:** NOT REFERENCED from CONFIGURATION.
- **0D:** NOT REFERENCED from DISABLE.
- **0E:** NOT REFERENCED from READY.
- **0F:** NOT REFERENCED from MOVING.
- **10:** NOT REFERENCED no parameters.
- **14:** CONFIGURATION.
- **1E:** HOMING.
- **28:** MOVING.
- **32:** READY from HOMING.
- **33:** READY from MOVING.
- **34:** READY from DISABLE.
- **3C:** DISABLE from READY.
- **3D:** DISABLE from MOVING.

NOTES

THE ERROR BUFFER GETS UPDATED PERIODICALLY, APPROX. EVERY 1 MS.

THE TS COMMAND READS THE ERROR BUFFER AND CLEARS THE ERROR BUFFER AT THE SAME TIME (SAME AS FOR COMMANDS TE, TB). SO WHEN LAUNCHING THE TS COMMAND, IT IS IMPORTANT TO PROCESS THE TS FEEDBACK ACCORDINGLY.

THE ERROR “NO PARAMETERS” GETS ONLY DETECTED DURING THE BOOTING OF THE CONTROLLER. WHEN READ THE ERROR IS CLEARED.

With no errors in the error buffer the color of the LED will change from red to either green or orange depending on the controller state.

Errors	A	—	Unknown message code or floating point controller address.
	B	—	Controller address not correct.
Rel. Commands	TE	—	Get last error.
Example	1TS		<i>Get error and state of controller #1.</i>
	1TS00000A		<i>Controller returns: no errors and NOT REFERENCED from reset.</i>

VE — Get controller revision information

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxVE				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [string]	—	Action.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
		Floating point:	Error A.		
Description	This command returns the controller’s revision information.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
Rel. Commands	TP	—	Get current position.		
Example	1VE		Get controller #1 revision information.		
1VE CONEX-AGP V1.0.0. Controller returns revision number					

ZT — Get all configuration parameters

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	—	—
	Syntax	xxZT				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
Description	The ZT command returns the list of all current configuration parameters.					
	The ZT command allows a quick review of all current stage parameter and simplifies the configuration of non Newport stages, for instance by using Hyper Terminal file transfer.					
Errors	A	—	Unknown message code or floating point controller address			
	B	—	Controller address not correct			
Rel. Commands	TE	—	Get error code.			
Example	1ZT		Get controller #1 configuration data.			
	1PW1					
	1DB0.000075					
	1KP10					
	...					
	1HT1					
	1PW0					

3.0 Connector interfaces

3.1 USB (Male mini-USB)

1 2 3 4 5



USB
Mating connector:
Plug Mini-USB B 5 cts

PIN	DESCRIPTION
1	+5VdcIN Do not connect if comm connector is used
2	DATA-
3	DATA+
4	NC
5	GND

Your Local Representative

Fax: _____

Return authorization #: _____

Date: _____

Phone Number: _____

Fax Number: _____

Serial #: _____

Serial #: _____

Reasons of return of goods (please list any specific problems): _____

Reasons of return of goods (please list any specific problems): _____



Visit MKS | Newport Online at:

www.newport.com

North America & Asia

Newport Corporation
1791 Deere Ave.
Irvine, CA 92606, USA

Sales

Tel.: +1 (949)-863-3144
e-mail: sales@newport.com

Technical Support

Tel.: +1 (949)-863-3144
e-mail: tech@newport.com

Service, RMAs & Returns

Tel.: +1 (949)-863-3144
e-mail: service@newport.com

Europe

MICRO-CONTROLE Spectra-Physics S.A.S
7 rue des Plantes
45340 Beaune-la-Rolande
France

Sales Europe (EMEA)

Tel.: +49 (0) 6151-708-0
e-mail: germany@newport.com

Sales France

Tel.: +33 (0)1 60 91 68 68
e-mail: france@newport.com

Sales UK

Tel.: +44 (0)1235 432 710
e-mail: uk@newport.com

Technical Support

e-mail: tech_europe@newport.com

Service & Returns

Tel.: +33 (0)2 38 40 51 55
DST-BEA-RMA-service@newport.com